



LSV Manual Technical Sheet::475 604 011 0

LSV Manual 475 604 011 0 Technical Sheet

1. Range of adjustment empty: 1.4 ... 2.8 bar
 2. Range of adjustment 1/2 laden: 3.4 ... 4.3 bar
 3. Range of adjustment fully laden: Reservoir pressure
 4. Empty pre-set: 2.1-0.2 bar
 5. Port threads: M 22x1.5
-



