



09.362.72.20.0

BPW replacement brake caliper TS2 3709

BPW replacement brake caliper (pre greased)

incl. guide pins and attachment parts

brake caliper without brake pad 05.362.72.20.0 (type plate)

Item 702 can be retrofitted as an option.

Important installation instruction:

First fit cylinder head screw 325 in the long fixed bearing (mark 1 on the brake caliper) and then cylinder head screw 345 in the short

floating bearing (mark 2 on the brake caliper) and tighten at the tightening torque of **260 Nm** (250 - 270 Nm).

Item	Name	BPW code number	Dimension	Quantity
323	Repair kit guide pins TS2	09.801.08.69.0	for one axle side	1
324	Repair kit cylinder head screw + sealing cap TS2	09.801.08.71.1	for one axle side	1
325	Cylinder head screw	03.340.12.32.0	M 16 x 1,5 x 103 - 10.9 / SW 14	1
326	Guide pin, long (fixed bearing)	05.001.00.70.0	Ø 18 / 26 / 37 x 123	1
328	Guide bush (fixed bearing)	03.112.33.13.0	Ø 37 / 41 x 73	1
335	Sealing cap	05.001.00.45.0	M 49 x 1,5 / SW 14	2
336	O-ring	02.5679.97.40	Ø 45 x 2	2
345	Cylinder head screw	03.340.12.31.0	M 16 x 1,5 x 73 - 10.9 / SW 14	1
346	Guide pin, short (floating bearing)	05.001.00.73.0	Ø 18 / 26 / 37 x 70	1
348	Guide bush (floating bearing)	03.112.33.16.0	Ø 37 / 41 x 34	1
354	Bellow	05.130.08.30.0	Ø 49 x 36	2
355	O-ring	02.5680.08.00	Ø 35 x 2	1
356	Ring	03.310.11.20.0	Ø 37 / 48 x 5,4	2
361	Repair kit bellow	09.801.08.81.0	for one axle	1



Item	Name	BPW code number	Dimension	Quantity
363	Bellow	05.130.08.32.0	Ø 40.7 / 75.4 Only deliverable per kit 09.801.08.81.0!	1
370	Cap	03.211.10.11.0	Ø 36.5 x 20.5 Only deliverable per kit 09.801.08.69.0 / 09.801.09.30.0 / 09.801.08.72.0 (TS2 3709) / 09.801.08.73.0 (TS2 4309)	1
373	BPW ECO Disc Grease	02.1040.60.00	25 g	1
395	Pad holding bar	03.001.00.64.0	151 x 42 Only deliverable per kit 09.801.08.70.0	1
702	Wear sensor set TS2	05.801.48.92.0		1

